

FIXING INSTRUCTIONS KOZ SQ 25-35

CONFIGURATION: SIDE HOLES INSTALLATION

Recommended torque moment: 5-8 Nm

Clamp Assembly Components:

2x Threaded rods | 4x Washers | 6x Nuts | 1x Cable cleat

Installation notes:

- To ensure a safe and guaranteed installation, apply force evenly
- In general apply force until you feel a slight resistance

1

Threaded rods configuration

Place the threaded rods in the bottom part using the nuts and washers.

Recommended torque: 5-8 Nm.

**2**

Cables

Secure the bottom part of the cable cleat using two nuts and then place the cables accordingly unto the bottom part.

Recommended torque: 5-8 Nm.

**3**

Upper part

Position the upper part over the cables and secure with washers and nuts.

Recommended torque: 5-8 Nm.

