

FIXING INSTRUCTIONS KOZ ST RANGE

CONFIGURATION: SIDE HOLES INSTALLATION

Recommended torque moment: 5-8 Nm

Clamp Assembly Components:

2x Threaded rods | 4x Washers | 6x Nuts | 1x Cable cleat

Installation notes:

- To ensure a safe and guaranteed installation, apply force evenly
- In general apply force until you feel a slight resistance

Compatible with KOZ® ST-series cable clamp types:

ST 18-26 | ST 26-38 | ST 36-52 | ST 50-75 | ST 75-100 | ST 75-105 | ST 100-130 | ST 120-160

1

Threaded rods configuration

Place the threaded rods in the bottom part using the nuts and washers.
Recommended torque: 5-8 Nm.

**2**

Cables

Secure the bottom part of the cable cleat using two nuts and then place the cables accordingly unto the bottom part.
Recommended torque: 5-8 Nm.

**3**

Upper part

Position the upper part over the cables and secure with washers and nuts.
Recommended torque: 5-8 Nm.

