

FIXING INSTRUCTIONS KOZ TRI RANGE

CONFIGURATION: 4-BOLT SYSTEM INSTALLATION

Recommended torque moment: 5-8 Nm

Clamp Assembly Components:

2x Threaded rods | 2x Big washers | 6x Big nuts | 4x Bolts | 2x Fixing plates
2x Small washers | 6x Small nuts | 1x Cable cleat

Installation notes:

- To ensure a safe and guaranteed installation, apply force evenly
- In general apply force until you feel a slight resistance

Compatible with KOZ® TRI-series and KOZ® TRI eco-series cable clamp types:

TRI 15-24 | TRI 25-40 | TRI 38-53 | TRI 67-82 | TRI 82-98 | TRI eco 67-82

1

Threaded rods configuration

Place the threaded rods in the bottom part using the nuts.

Recommended torque: 5-8 Nm.

4x

**2**

C-profile / Rail configuration

Place and secure the bottom part of the cable cleat on the rail using the fixing plates, washers and bolts in the bottom part.

Recommended torque: 5-8 Nm.

2x



4x



4x



4x

**3**

Upper part

Place the cables accordingly unto the bottom part. Position the upper part over the cables and secure with washers and nuts.

Recommended torque: 5-8 Nm.

2x



2x

